



NÁVOD NA MONTÁŽ:

Kód: H0885(A,I,C)

- 1. Demontujte spodný plastový kryt podvozku. Demontujte nárazník.
- 2. Ťažné zariadenie montujte po častiach podľa obrázka. Ťažné zariadenie montujte bez gule a puzdra. Na upevňovacie otvory zľahka priskrutkujte postranné pätky A a B, na ne naskrutkujte rám ťažného zariadenia C. Skrutkové spoje dotiahnite momentom podľa tabuľky.
- 3. Vyrežte vybranie do spodného plastu nárazníka podľa obrázka – DETAIL
- 4. Elektroinštaláciu zapojte podľa návodu.
- 5. Skontrolujte správnosť pripojenia elektroinštalácie.
- 6. Prevedte spätnú montáž demontovaných častí. Plastový kryt prispôbte.
- 7. Dotiahnite skrutkové spoje spojovacej gule (držíaka spojovacej gule) momentom podľa tabuľky.

FITTING INSTRUCTIONS:

- 1. Remove the under plastic surfacing for chassis. Remove the bumper.
- 2. Install the tow-bar in parts to picture. Install the tow-bar without towball and case. Freely screw the side base A and B on the fixing holes and then screw the frame of the tow-bar C on it. Then tighten the screw connections by the torque table.
- 3. Cut out the removal in to the under plastic cover bumper – picture DETAIL
- 4. Connect the electrical installation as described in the instructions for use.
- 5. Make sure the electrical installation is properly connected.
- 6. Reassemble any removed parts. Plastic cover to customize.
- 7. Make sure the screws of the linkage ball (holder of the linkage ball) are tightened to the torque shown in the table.

DÔLEŽITÉ UPOZORNENIA:

- V miestach stykových plôch sa musí odstrániť pružná ochrana karosérie vozidla.
- Vŕtané otvory treba ošetriť antikoróznou hmotou.
- Použite len dodaný spojovací materiál v predpisanej triede kvality.
- Elektrické zariadenie sa namontuje podľa podmienok prevádzky cestných vozidiel na pozemných komunikáciách.
- Údaj S o maximálnom zvislom zaťažení na guľu je uvedený na výrobnom štítku ťažného zariadenia.
- Na ťažnom zariadení nie je možné nič upravovať ani meniť.
- Pred ukončením montáže je nutné prekontrolovať všetky spoje podľa tabuľky uťahovacích momentov!
- V prípade akýchkoľvek nejasností je nutné obrátiť sa na výrobcu ťažného zariadenia.
- Výrobca nenesie zodpovednosť za škody spôsobené nesprávnym použitím výrobku.

IMPORTANT ATTENTIONS:

- Remove insulating material on a car body in grips and joints of a coupling device with a car body.
- Put the anticorrosive substance on the drilled holes.
- Use supplied mechanical strength jointing material.
- Wiring of a coupling device must be up to a standard and car maker requirements.
- Statement S about the maximum vertical ball downtake is printed on the tow bar label.
- On the tow bar is no modification possible
- Check all the joints, look in the table of the spining moments, before finishing the montage!
- Contact the tow bar marker with any questions.
- The manufacturer is not responsible for the damages caused by wrong using on the product.

Tabuľka uťahovacích momentov skrutkových spojov pevnosti 8.8 / Table of specified torque and hardenss settings 8.8

M6 - 9,5Nm, **M8** - 23Nm, **M10** - 46Nm, **M10x1,25** - 49Nm, **M12** - 79Nm, **M12x1,25** - 87Nm, **M12x1,5** - 83Nm, **M14** - 125Nm, **M16** - 195Nm