
### FITTING INSTRUCTION



This towbar is designed to assembly in following cars: CHEVROLET LACETTI ESTATE, produced since 2005, catalogue no. X18 and is prepared to tow trailers max total weight 1200 kg and max vertical load 75 kg.

### From manufacturer

Thank you for buying our product. Their reliability has been confirmed in many tests. Reliability of towbar depends also on correct assembly and correct exploitation. For this reasons we kindly ask to read carefully this instruction and apply to hints.

The towbar should be install in points described by a car producer.

## The instruction of the assembly

- 1. Disassemble a rear bumper.
- 2. Unscrew reinforcement of the bumper, next unscrew fastening handles.
- 3. Reinforcement fix to the main bar of the towbar (pos. 1) in points pos. A.
- 4. Put towbar into chassis members and fix using bolts from towbar equipment see figure.
- 5. Screw tow-ball (pos. 2) and socket plate (pos. 3) using bolts M12x70mm (pos. 5) from equipment
- 6. Tighten all bolts according to the torque shown in the table.
- 7. Connect electric wires of 7-poles socket according to the instruction of the car. (Recommend to make at authorized service station)
- 8. Complete paint layer damaged during installation.

Torque settings for nuts and bolts (8,8):		
<b>M 10 -</b> 50 Nm <b>M16 -</b> 210 Nm		


### NOTE

After install the towbar you should get adequate note in registration book (at authorised service station). The car should be equipped with:

- Indicators
- Tow mirrors

After 1000km of exploitation check all bolts and nuts. The ball of towbar must be always kept clear and conserve with a grease.

#### Towbar equipment:





# Towing hitch (without electrical set)

Class: A50-X Cat. no. X18 Designed for: Manufacturer: CHEVROLET Model: LACETTI Type: ESTATE produced since 2005

Technical data: D-value: 6,95 kg maximum trailer weight: 1200 kg maximum vertical cup load: 75 kg

#### Approval number acc. to regulations EKG/ONZ 55.01: E20-55R-01 1809

#### Foreword

This towbar is designed according to rules of safety traffic regulations. The towing hitch is a safety component and can be install only by qualified personnel. Any alteration or conversion of the towing hitch is prohibited and would lead to cancellation of design certification. Remove insulating compound and underseal from vehicle (if present) in the area of the matting surfaces of the towing hitch.

The vehicle manufacturer's specifications regarding trailer load and max. vertical cup load are decisive for driving, and values for the towing hitch cannot be exceeded.

D-value formula:

$$\frac{\text{Max trailer weight [kg]}}{\text{Max trailer weight [kg]}} \times \frac{\text{Max vehicle weight [kg]}}{\text{Max trailer weight [kg]}} \times \frac{9,81}{1000} = D [kN]$$

# PPUH AUTO-HAK S.J.

Produkcja Zaczepów Kulowych Henryk i Zbigniew Nejman 76-200 SŁUPSK ul. Słoneczna 16K tel/fax (059) 8-414-414; 8-414-413 E-mail: office@autohak.com.pl www. autohak.com.pl